

Original Greenstar Autotrac

Autotrac Setup

1. From Run Page 3
2. Press "Setup"
3. Select "A" Tracking
4. Select Tracking Mode
5. Press "B" to change Implement width
6. Press "Page"
7. Configure Tones, Turning View, Turn Predictor
8. Press "Run"

Set Track Zero (A-B Line Method)

1. From Run Page 3
2. Press "Setup"
3. Press "A" Tracking
4. Press "C" to choose and existing A-B Line OR
5. Select "F" To Save Point A.
6. Drive to the other end of the field or pass.
7. Press "D" To Save Point B
8. Press "Run"
9. Press "E" to turn steering "On" (Run Page 3)
10. Press Resume switch to begin Tracking

Set Track Zero (Heading Method)

1. From Run Page 3
2. Press "Setup"
3. Press "A" Tracking
4. Press "C" to choose and existing A-B Line OR
5. Select "F" Save Point A.
6. Press "F" Again to use Track Heading
7. Key in desired heading (0 and 360=North, 90=East, 180=South, 270=West) (Any heading can be entered. A few degrees off of a due heading is good for Harvest and Tillage ie: 98 degrees or 172 degrees ect...)
8. Press "F" again to save
9. Press "Run"
10. Press "E" to turn steering "On" (Run Page 3)
11. Engage Resume switch to begin Tracking